

# PHILIPS



## PAL-COLOUR PATTERN GENERATOR

**PM 5508**

(9449 055 080.1)

9499 490 04911

11/369/3/02/03/04



# PHILIPS

## Operating manual

### PAL-COLOUR PATTERN GENERATOR

**PM 5508**

(9449 055 080.1)

9499 490 04911

11/369/3/02/03/04

# Contents

GENERAL	Page
<b>I. Introduction</b>	<b>5</b>
<b>II. Technical data</b>	<b>7</b>
<b>III. Accessories</b>	<b>11</b>
<b>IV. Description of the block diagram</b>	<b>12</b>
OPERATING INSTRUCTIONS	
<b>V. Installation</b>	<b>19</b>
A. Adjusting to the local mains voltage	19
B. Earthing	19
C. Connections	19
<b>VII. Application</b>	<b>23</b>
<b>VI. Operation</b>	<b>21</b>
A. Pattern 1 : "CHECKERBOARD"	24
B. Pattern 2 : "WHITE"	28
C. Pattern 3 : "RED"	29
D. Pattern 4 : "GREYSCALE"	31
E. Pattern 5 : "DOTS"	33
F. Pattern 6 : "CROSSHATCH"	35
G. Pattern 7 : "DELAY"	38
H. Pattern 8 : "PHASE"	44
I. Pattern 9 : "MATRIX"	50
J. Pattern 10 : "COLOUR BAR"	52
K. Adjusting with the oscilloscope	58
Addresses	81

## List of figures

		Page
IV-1	Block diagram	15
VI-1	Controls and sockets	21
VII-1	"CHECKERBOARD"-pattern	24
VII-2	Incorrect vertical amplitude and linearity	25
VII-3	Incorrect centring	26
VII-4	"WHITE"-pattern	28
VII-5	"RED"-pattern	29
VII-6	Typical purity error	30
VII-7	"GREYSCALE"-pattern	31
VII-8	"DOTS"-pattern	33
VII-9	Detail of incorrectly converged picture	34
VII-10	"CROSSHATCH"-pattern	35
VII-11	Incorrect horizontal dynamic convergence	36
VII-12	Picture detail in case of incorrect dynamic convergence	36
VII-13	"DELAY"-pattern	38
VII-14	Vectorscope display of the "DELAY"-pattern	39
VII-15	Picture detail showing the "Venetian blinds" effect	40
VII-16	"Venetian blinds" in bar 3 (detail)	41
VII-17	"Venetian blinds" in bar 2 (detail)	41
VII-18	"PHASE"-pattern	44
VII-19	Vectorscope display of the "PHASE"-pattern	45
VII-20	Incorrect subcarrier phase to the (R-Y) demodulator	46
VII-21	Incorrect subcarrier phase to the (B-Y) demodulator	47
VII-22	Incorrect subcarrier phase to both demodulators (R-Y) and (B-Y)	48
VII-23	"MATRIX"-pattern	50
VII-24	Vectorscope display of the "MATRIX"-pattern	51
VII-25	"COLOUR BAR"-pattern	52
VII-26	Vectorscope display of the "COLOUR BAR"-pattern	53
VII-27	Blue-colourdifference-signal of "COLOUR BAR"-pattern	54
VII-28	Red-colourdifference-signal of "COLOUR BAR"-pattern	55
VII-29	Green-colourdifference-signal of "COLOUR BAR"- pattern	56
VII-30	Correctly adjusted delay-line	58
VII-31	Amplitude error in delay-line	59
VII-32	Phase error in delay-line	59
VII-33	Both demodulators adjusted correctly	60

	<b>Page</b>	
VII-34	Only (R-Y) demodulator adjusted incorrectly	<b>61</b>
VII-35	Only (B-Y) demodulator adjusted incorrectly	<b>61</b>
VII-36	Both demodulators adjusted incorrectly	<b>61</b>
VII-37	Correct (G-Y) signal	<b>62</b>
VII-38	Incorrect (G-Y) signal	<b>63</b>
	Circuit diagrams	<b>66, etc.</b>

### **IMPORTANT**

In correspondence concerning this instrument, please state the type-, serial- and instrument number as given on the identification plate at the rear of the instrument.

# GENERAL

## I. INTRODUCTION

The PHILIPS PAL-colour pattern generator PM 5508 is an all solid state, mains supplied instrument. It is intended for use when installing, fault-tracing and repairing colour TV sets operating according to the PAL systems G and I and black/white TV sets operating according to the 625 lines CCIR systems B, I, G and H. The PM 5508 is suited for use with colour-TV receivers of various principles, the circuits of which could differ in many ways, e.g. R - G - B control of the picture tube instead of control with (R-Y), (G-Y) and (B-Y) and Y, separation of luminance and chrominance signal in the video stage instead of with the aid of an additional I.F. chroma detector, etc.

Therefore the instrument is designed so that it produces ten test signals, by means of which the complete receiver performance can be checked by simply observing the patterns on the screen. A complete test will only take a few minutes. If during this test it is observed that the receiver requires realignment, the latter can easily and accurately be done with the aid of the generator signals. Re-adjustments of the delay-line circuit, the chroma-demodulators and the amplitude-ratio of the colour-difference signals can even be carried out by simply using the screen of the receiver as an indicator.

The instrument moreover has the following features:

- The RF output signal covers the VHF- and UHF ranges.
- Presetting of 4 channels in the VHF range and any 4 channels in the UHF range; instead of one VHF-channel, the IF vision carrier can be preset.
- RF output signal continuously adjustable and sufficiently high to supply several receivers simultaneously.
- Sound carrier can be switched on/off.
- Sound carrier can internally be modulated with 1 kHz.

- Burst amplitude continuously adjustable between 0 and 200%, fixed nominal position.
- Composite 1 Vp-p video signal externally available.
- "LINE-" and "FRAME SYNC." signals externally available for triggering purposes.
- Handy, small and light-weight instrument suited for workshop as well as mobile service.

## II. TECHNICAL DATA

Properties expressed in numerical values with tolerances stated, are guaranteed by us. Numerical values without tolerance are intended for information purposes only and indicate the properties of an average instrument.

### Vision carrier:

IF	38.9 MHz
Band I	55 ... 70 MHz
Band III	173 ... 225 MHz
Band IV/V	470 ... 850 MHz

Push-buttons enable presetting of any 4 UHF channels and 4 VHF channels or 3 VHF channels and the vision IF carrier.

### Spacing of vision and sound carriers:

PM 5508B:	6.0 MHz (CCIR system I; PAL system I)
PM 5508E:	5.5 MHz (CCIR systems B, G and H; PAL system G)
Frequency drift of sound subcarrier:	$\pm 0.1\%$ ( $10^{\circ}$ ... $40^{\circ}$ C)

### Video modulation:

Modulation	AM, negative
Residual carrier	15% at 100% white
Vision modulator	balanced diode type; max unbalance 5%
Differential phase	$< 5^{\circ}$

### Sound modulation:

Modulation	FM
Sweep	$\pm 50$ kHz
Distortion	$< 3\%$
Internal modulation	1 kHz, sine wave
Modes of operation	— sound carrier off
	— unmodulated
	— modulated with 1 kHz

### Encoding

System	PM 5508B: PAL-I PM 5508E: PAL-G
Subcarrier	4.433619 MHz
Frequency drift of subcarrier	$\pm 20$ Hz ( $10^\circ \dots 40^\circ$ C)
Burst width	approx. 10 cycles of subcarrier
Burst amplitude	"NOM" position: equal to sync. signal.
Burst phase	Adjustable: from approx. 0% to 200%. line sequential: $180^\circ \pm 45^\circ$
Burst position	5.6 $\mu$ s after leading edge of line sync. pulses
Chroma modulators	balanced diode type
Chroma bandwidth	1.1 MHz (3dB)
Group delay precorrec- tion of chroma signal	— 175 ns
Colour matrixing	$Y = 0.30 R + 0.59 G + 0.11 B$

### Patterns

"CHECKERBOARD"	6 x 8 black/white squares, accurately centred.
"WHITE"	100% white signal with PAL-alternating burst.
"RED"	fully saturated red signal with PAL-alternating burst.
"GREYSCALE"	staircase signal with 8 identical steps.
"DOTS"	white dots; location corresponds to the intersections in the lrossshatch pattern.
"CROSSHATCH"	11 horizontal white lines; width: on line per field 15 vertical white lines; width: 200 ns. The horizontal and vertical white lines form black squares, accurately centred.

- "DELAY" 4 vertical bars:  
 $146^\circ : (G-Y) = 0,$   
 $180^\circ : (R-Y) = 0,$   
 $90^\circ : (B-Y) = 0$  } luminance 40%  
 grey  
 NTSC encoded, however with PAL-alternating burst.
- "PHASE" same bars as "DELAY" with PAL-alternating burst.  
 However, upper part: PAL encoded with reduced saturation, and lower part: only chroma during the "positive" PAL-lines, where burstphase =  $135^\circ$ .
- "MATRIX" same bars as "DELAY" with PAL-alternating burst, however, completely PAL encoded.
- "COLOUR BAR" 75%-contrasted picture. Upper part: colour bar signal with 8 vertical bars: white, yellow, cyan, green, magenta, red, blue and black. Lower part: white.

Bar	Relative luminance amplitude	Chroma phase	Relative chroma amplitude
White	0.75	—	—
Yellow	0.67	$167^\circ$	$\pm 0.33$
Cyan	0.53	$283^\circ$	$\pm 0.47$
Green	0.44	$241^\circ$	$\pm 0.44$
Magenta	0.31	$61^\circ$	$\pm 0.44$
Red	0.23	$103^\circ$	$\pm 0.47$
Blue	0.08	$347^\circ$	$\pm 0.33$
Black	0	—	—

### Synchronisation and blanking

- Line frequency 15625 Hz  $\pm 0.1\%$   
 Field sync. pulse width 2.5 lines  
 (no inverted line pulses during field sync. pulse, no equalizing pulses, no interlacing)

Line sync. pulse	width	4.8 $\mu$ s
	frontporch	1.9 $\mu$ s
	blackporch	6.1 $\mu$ s
Field blanking		24 lines
Line blanking		12.8 $\mu$ s
Total field period		312 lines
Active field period		288 lines
Total line period		64 $\mu$ s
Active line period		51.2 $\mu$ s
Set-up between black level and blanking		5%
Sync. to picture ratio		30 : 70

## Outputs

### Socket "RF"

For UHF	20 mV *), if loaded with 75 $\Omega$ or 40 mV *), if loaded with 300 $\Omega$ (via matching transformer 75 $\Omega$ $\rightarrow$ 300 $\Omega$ )
	continuously adjustable
For VHF	15 mV *), if loaded with 75 $\Omega$ or 30 mV *), if loaded with 300 $\Omega$ (via matching transformer 75 $\Omega$ $\rightarrow$ 300 $\Omega$ )
	continuously adjustable
Output impedance	75 $\Omega$
Amplitude ratio vision to sound carrier	4 : 1
Connector	BNC, female

### Socket "VIDEO"

Voltage	1 Vp-p, if loaded with 75 $\Omega$
Polarity	white positive — sync. negative
Output impedance	75 $\Omega$
Connector	BNC, female

### Sockets "SYNC."

Signal	optionally: — line frequency pulses — field frequency pulses to be selected with switch "SYNC."
--------	--

\*) RMS-value of the vision carrier during the peaks of the modulation envelope.

Amplitude	5 V <sub>p-p</sub> , unloaded
Polarity	positive
Output impedance	10 k $\Omega$
Connectors	4 mm banana sockets

### Supply

Mains voltage	115 V or 230 V, $\pm$ 20%
Mains frequency	50—60 Hz
Power consumption	15 W at 220 V
Safety fuse	200 mA, delayed action type

### Mechanical data

Dimensions	Modular cabinet
Height x width x depth	195 x 305 x 275 mm (width: 4 units)
Weight	6.1 kg

## III. ACCESSORIES

- 1 Operating manual
- 1 Mains flex
- 1 RF cable with, only with PM 5508E, a matching transformer 75  $\Omega$   $\rightarrow$  300  $\Omega$

#### IV. DESCRIPTION OF THE BLOCK DIAGRAM

(See Fig. IV-1)

To obtain a constant ratio between line synchronising pulses, field synchronising pulses and the various patterns, the circuits of the instrument are controlled by a master oscillator. The frequency of this oscillator (312.5 kHz) is divided by means of a 2 : 1 divider in order to obtain the pulses "a", which control the horizontal information in the patterns. This divider is followed by another 2 : 1 divider and a 5 : 1 divider in order to obtain pulses of line frequency ("lb" and "ls").


Furthermore, the line frequency is successively divided by 2, by 4, by 3, and by 13 in order to obtain pulses having the field frequency ("fb" and "fs"). These dividers also supply pulses to control the vertical information in the patterns ("24 l", "312 l", from which are derived "~ b" and "96 l").

The luminance signal, the black/white patterns, the convergence patterns and the composite synchronising and blanking signal are generated on the basis of the afore mentioned horizontal and vertical control pulses.

These signals are added in the luminance-sync.-blanking adder and passed on, via the delay line, the video amplifier, where the composite luminance signal is added to the chrominance signal. The delay line (0.375  $\mu$ s) compensates for the time delay which arises when the colour signals are encoded. The R, G, and B signals are generated in the colourbar generator. This generator is followed by a matrix, "adding" the R, G, and B signals in such a way that the correct Y, (R-Y), and (B-Y) signals are obtained. The step signal (Y') of the greyscale signal is also generated in this matrix.

The colour subcarrier signal is supplied by a crystal-controlled oscillator. The phase of the subcarrier to the (B-Y) modulator is shifted 90° in a phase shifting circuit, in order to obtain the correct quadrature of (R-Y) and (B-Y). In a PAL switching circuit the phase of the subcarrier to the (R-Y) modulator is inverted line sequentially, in order to obtain the PAL encoding. The PAL switching circuit can be cut out during the moments, that the generator has to produce an NTSC encoded signal (test signal "DELAY"). During this signal, however, the PAL switch actually operates briefly during the line backporch to produce the PAL-alternating burst. This is controlled by the "2 l" pulses. The colour-difference signals and the burst keying pulses (the latter are derived from the "ls" pulses) are applied to the (R-Y) and (B-Y) modulators. These modulators are balanced modulators together supplying the chrominance signal in which the carrier wave has been suppressed. The chrominance signal is added to the luminance signal in the video amplifier.

The sound subcarrier is generated in a 5.5 MHz (6 MHz in the B-version) oscillator. Via a switch, this subcarrier can be frequency-modulated with 1 kHz by means of a modulator, operating according to the diode switching principle. This subcarrier oscillator itself can be switched off if desired. In an adder stage the sound subcarrier is added to the composite video signal. From there it is applied to an RF modulator and, via an RF attenuator, to output socket "RF". The instrument is provided with an stabilised power supply with short-circuit protection circuit.



PEM 4038

Fig. IV-1. Block diagram

# OPERATING INSTRUCTIONS

## V. INSTALLATION

### A. Adjusting to the local mains voltage

The instrument can be used with mains voltages of 115 V a.c.  $\pm 20\%$  and 230 V a.c.  $\pm 20\%$ .

If the instrument has to be adjusted to another mains voltage, resolder the connections to the primary windings of the supply transformer as shown in the sticker on the transformer.

To gain access to the supply transformer and fuse:

- Remove the bottom plate (two screws), the transformer-connections are then accessible.
- Remove the two screws holding the printed wiring unit which should then be hinged out.
- The fuse (200 mA, delayed) is then accessible.

### B. Earthing

Earth the instrument in accordance with the local safety regulations. This can be done via the mains flex, as it is equipped with a plug with rim-earthing contacts, or via the earth-screw at the rear of the instrument. Not only the metal cabinet is then earthed but also the "common" of the circuit.

**Avoid double earthing.**

### C. Connections

RF:

- Connect the generator to the mains by means of the mains flex supplied.
- Connect socket "RF" to the receiver to be checked by means of a RF cable and, if necessary, via the  $75\ \Omega \rightarrow 300\ \Omega$  matching transformer.
- The measuring set-up then is ready (see the section "OPERATION" on page 21).

**VIDEO:**

Circuits requiring an encoded colour video signal or a black/white video signal (e.g. monitors, decoders, video tape-recorders, etc.) should be connected to socket "VIDEO" by means of a coaxial  $75\ \Omega$  cable. A positive video signal with an output impedance of  $75\ \Omega$  can be taken from this socket. If loaded with  $75\ \Omega$ , the output amplitude is 1 Vp-p.

**SYNC.:**

If an oscilloscope is to be triggered externally for some measurements, connect the sockets "SYNC." to the external trigger input of the oscilloscope.

Set switch "SYNC." to position "LINE" in case this triggering is to take place in the line sync.-pulse-rhythm and to position "FRAME" in case of triggering with field-sync. pulses. The polarity of the trigger pulses is positive.

## VI. OPERATION

The following is a description of the procedure for tuning the generator to a colour receiver and for adjusting the "customer controls" of the colour receiver to their proper settings. It is obvious that this procedure probably cannot be completed if the receiver is defective.

- Make the connections as indicated in section "INSTALLATION", part C: "Connections-RF", page 19.
- Connect the colour receiver to the mains.

### Warning

In most TV-receivers equipped with valves, the heaters are series connected; one pole of the mains is then connected direct to the chassis. Therefore, before measuring on the receiver, connect it to the mains via a separating transformer.

- Switch on the colour receiver.
- Switch on the generator (switch "POWER" to position "ON"). One of the channel scales will be illuminated, depending on whether a VHF- or an UHF-button is depressed.
- Turn control "BURST AMPL." fully anti-clockwise (switch to position "NOM", clicking sound!).




Fig. VI-1. Controls and sockets

- Set control "RF OUTPUT" to "10 mV".
- Depress switch "COLOUR BAR" and set switch "SOUND CARRIER" to position "MOD."

**Note:**

With the exception of the colour settings, the tuning, etc., of the black/white receiver to the generator is identical to the described procedure for colour receivers. In this case, however, use the "CHECKERBOARD"-pattern.

- Tune \*) the generator to the channel to which the receiver is adjusted (the receiver should not be tuned to one of the local transmitters). As the generator produces a double sideband RF signal, be sure to tune to the correct sideband (the one that is highest in frequency), i.e. first set the generator to a channel that is **lower** than the one to which the receiver is adjusted and then tune the generator to the receiver. The **first** sideband "encountered", is the correct one.  
The receiver can also be tuned to the channel setting of the generator. In that case the receiver should first be set to a **higher** channel than the generator, etc.
- Carry out the fine tuning adjustments so that the picture on the receiver contains colour, while at the same time there is no "sound in the picture".
- Set the generator to the "GREYSCALE" pattern.
- Adjust controls "BRIGHTNESS" and "CONTRAST" of the receiver to obtain correct settings, i.e. the left vertical bar should be white and the right one should be black, while the bars in between should show six grey level steps increasing in darkness from left to right.
- Set the generator to the "COLOUR BAR" pattern.
- Adjust control "SATURATION" of the receiver to obtain the correct setting, i.e.: first turn it fully anticlockwise and increase the saturation until the green and the blue dots in the red bar just disappear.
- The "customer-controls" of the receiver then are properly adjusted.

\*) The push-buttons for channel selecting can be pre-set to any channel within the range of the generator. To change a presetting, turn the button while it is depressed. The dial pointer will indicate the selected channel.

## VII. APPLICATION

The generator supplies ten specially selected test signals for colour as well as for black/white. All these signals can be switched on by means of push-buttons, which are arranged for obtaining the signals in the optimum sequence for testing. First the basic black/white tests are made and then the special colour tests.

- The sections marked with a red dot are for colour-receivers only while the
- others, marked with a black dot, are for colour as well as for black/white receivers.

The description on the following pages is intended to give the user an impression of a checking procedure for receivers. At the same time an explanation of the colour patterns is given in small print.

### CHECKING THE TUNER(S) OF THE RECEIVER

Due to a modification in the VHF tuner, the frequency limit at the beginning of Band I has been shifted so that the range around channel 2 (CCIR, system B) is replaced by the IF range common for TV receivers (around 38.9 MHz). The indication "2" on the VHF channel scale is therefore replaced by the indication "IF".

The user can now determine whether the incorrect functioning of the receiver is due to a defect in the channel selector.

#### *Procedure*

If, when following the procedure described in chapter VI "OPERATION", there is doubt whether the incorrect functioning of the receiver is due to a defect in the channel selector, proceed as follows:

1. Depress button "BL/WH" (checkerboard) and set switch "SOUND CARRIER" to position "UNMOD."
2. Connect socket "RF" via a coaxial cable (without matching transformer) and an isolating capacitor, to the input of the first IF stage of the receiver. If necessary, temporarily unsolder the IF connection of this stage with the channel selector.
3. Tune the PM 5508 to the IF of the receiver, ensuring that the receiver is not overloaded (use control "RF OUTPUT" of the PM 5508).
4. If the receiver does operate properly yet, the defect will be located in the channel selector. We would like to emphasise that this IF signal of the PM 5508 *should not* be employed for any purpose other than described above.

A. **Pattern 1**  
"CHECKERBOARD"




Fig. VII-1. "CHECKERBOARD"-pattern

1. ● Check for correct horizontal and vertical synchronisation.
2. ● Check for correct position of the picture (deflection yoke).
3. ● Check for correct horizontal and vertical amplitude of the deflection (picture height and -width; the "CHECKERBOARD"-pattern consists of 6 x 8 squares).



Fig. VII-2. Incorrect vertical amplitude and linearity

4. ● Check for correct horizontal and vertical linearity of the deflection. Fig. VII-2 shows incorrect vertical amplitude and linearity.




Fig. VII-3. Incorrect centring

5. ● Check for correct horizontal and vertical centring of the picture. Fig. VII-3 shows incorrect centring.

6. ● Check the bandwidth. The vertical black/white transitions should be sharp and not "double" (risetime and ringing resp.).
7. ● Check the step-function response. The vertical transitions should not show any overshoot.
8. ● Check for mains-hum interference in the synchronisation of the picture.
9. ● Check the sensitivity of the receiver by means of control "RF OUTPUT".
10. ● Check the suppression of the sound intercarrier. No "sound" should appear in the picture when switch "SOUND CARRIER" is set to position "UNMOD".
11. ● Check that there is no "i.f. sound in the picture" due to e.g. microphony or excessive power consumption of the sound output stage. This should be done with switch "SOUND CARRIER" in position "MOD".
12. ● Check the proper functioning of the sound section of the receiver, e.g. by operating switch "SOUND CARRIER".

**B. Pattern 2.**  
"WHITE"




Fig. VII-4. "WHITE"-pattern

This pattern consists of a 100% white signal without chroma, but with PAL-alternating burst.

1. ● Check the picture for constant brightness over the entire screen (no hum, etc.).
2. ● Check the "white-C"-adjustment of the colour-picture tube (readjustment is required after e.g. replacement of the picture tube). This should be done with control "BURST AMPL" in position "NOM". Some colour receivers switch automatically from "black/white"-white to "colour"-white (standard White-C). This, the so-termed preferred-white adjustment, can be checked by setting control "BURST AMPL." from "0%" to "NOM" and back.
3. ● This pattern is also necessary to check and readjust the limiting of the beam-current of the colour picture tube. For details about this adjustment, refer to the Service Notes of the relevant receiver.

**C. Pattern 3.**

"RED"




Fig. VII-5. "RED"-pattern

This pattern consists of a fully saturated red signal with PAL-alternating burst.

1. ● First set the brightness and saturation controls of the receiver clockwise and then turn them anti-clockwise until the blue and green dots disappear and only the red dots remain.




Fig. VII-6. Typical purity error

2. ● Check the purity of red (this pattern offers the advantage that the green and blue guns need not be switched off). Larger convergence errors may have an effect on this check. Fig. VII-6 shows a purity error.
3. ● This pattern can also be used to check whether a black/white receiver suffers from excessive interference due to the colour subcarrier.


**D. Pattern 4.****"GREYSCALE"**

Fig. VII-7. "GREYSCALE"-pattern

This greyscale signal is a linear staircase signal. It has **not** been derived from the colour bar signal by removing its chroma-information.

1. ● Check the proper functioning and the range of the brightness and contrast controls of the receiver. In some receivers the black level is kept constant and is not effected by operation of the contrast while each of the 6 steps in between should show an equal increase of grey (from left to right).
2. ● Check the proper greyscale setting of the colour receiver. The various greybars should not contain any colour. (If the greyscale setting is not correct, the ratio between the beam current and the control grid curves of the three guns of the picture tube is not constant; re-adjust according to the instructions in the Service Notes of the relevant receiver).

3. ● The following check with this pattern requires the aid of the oscilloscope.

Check the non-linearity of the video amplifier of the receiver with the contrast control at maximum. Check that each step of this greyscale signal at the output of the video amplifier is equal. This can easily be measured by comparing it on the dual beam oscilloscope PHILIPS PM 3230 with the signal on socket "VIDEO".

E. **Pattern 5.**  
"DOTS"




Fig. VII-8. "DOTS"-pattern

1. ● Check and, if necessary, re-adjust the static convergence in the centre of the screen at low ambient brightness. This should be done according to the instructions of the manufacturer of the receiver. Fig. VII-9 shows a detail of an incorrectly converged picture.




Fig. VII-9. Detail of incorrectly converged picture


**F. Pattern 6.****"CROSSHATCH"**

Fig. VII-10. "CROSSHATCH"-pattern

1. ● Check and if necessary re-adjust the horizontal- and vertical dynamic convergence. This should be done according to the instructions of the manufacturer of the receiver. Fig. VII-11 shows incorrect horizontal dynamic convergence. Fig. VII-12 shows a picture detail in case of incorrect dynamic convergence.




Fig. VII-11. Incorrect horizontal dynamic convergence



Fig. VII-12. Picture detail in case of incorrect dynamic convergence

2. ● Check the focussing of the picture (adjustment of the d.c. level on the third grid of the picture tube). At the same time, an impression can be obtained of the horizontal and vertical linearity of the deflection, as the horizontal and vertical white lines should form squares. Moreover, it can also be determined if the receiver's amplitude response is correct. The vertical white lines have a width of 200 ns. If these lines appear "unsharp" and show considerably less intensity than the horizontal ones, the amplitude response of the receiver is insufficient. If the vertical white lines appear "double", the circuits of the receiver cause ringing.
3. ● Check the pin-cushion correction of the receiver. This correction requires readjustment if the white lines, horizontal as well as vertical, do not seem to be straight and parallel at normal viewing distance. See the Services Notes of the relevant receiver.

G. **Pattern 7.**  
"DELAY"




Fig. VII-13. "DELAY"-pattern

This pattern is designed especially for checking the PAL delay-line circuitry. If displayed on the screen of a colour receiver the first two bars should have a yellow/greenish colour and the other two should be grey (on some receivers these grey bars appear slightly bluish; this however is of no importance for this measurement).

The colour difference signals of this pattern are encoded according to the NTSC standard, i.e. the (R-Y) information is *not* line-sequentially reversed in phase. The burst in this signal, however, is normally encoded according to the PAL standard, i.e. the burst is line sequential in the  $135^\circ$  and  $225^\circ$  phases, see vector diagram, Fig. VII-14.



Fig. VII-14. Vectorscope display of the "DELAY"-pattern

1. ● If the colour of bar 3 (from the left) differs **considerably** from bar 4, first a coarse pre-adjustment of the subcarrier phase to the (B-Y) demodulator should be made.

This is because the chroma signal in bar 3 represents  $(B-Y) = 0$ , and only contains + (R-Y) information. If the (B-Y) demodulator produces an output signal during that bar, i.e. if that bar differs from bar 4 (the one without chroma), the subcarrier-phase to the (B-Y) demodulator will not be correct.




Fig. VII-15. Picture detail showing the "Venetian blinds" effect

2. ● The delay-line requires readjustment if the chroma contents of the successive TV lines does not seem to be the same and if the so-termed "Venetian blinds" appear (see Fig. VII-15).




Fig. VII-16. "Venetian blinds" in bar 3 (detail)



Fig. VII-17. "Venetian blinds" in bar 2 (detail)

3. ● Readjust the delay-line amplitude control for minimum "Venetian blinds" in bar 3 (see Fig. VII-16) and the delay-line phase control for minimum "Venetian blinds" in bar 2 (see Fig. VII-17). Do **not** look at the colours, but only for the appearance of the "Venetian blinds" effect!

Bars 1 and 2 contain the same amount of (B-Y) information, while bars 1 and 3 contain the same amount of (R-Y) information. Because this signal is encoded as an NTSC signal, the (R-Y) output of the delay line circuit in the receiver should eliminate all (R-Y) information during bars 1 and 3, see Fig. VII-13.

That is why bars 1 and 2 have the same colour (of  $180^\circ$ ) on the screen and bar 3 is grey like bar 4 (if the receiver is correctly adjusted). In case of incorrectly adjusted amplitude and phase controls of the delay-line, the (R-Y) demodulator will produce an undesired output signal which, due to the action of the (R-Y) switch, will cause a line-sequentially varying colour on the screen. This results in the appearance of "Venetian blinds".

If *only* bars 1 and 3 contain "Venetian blinds" the only possible cause is an amplitude deviation of the delay-line circuit. A phase error, however, will produce "Venetian blinds" in bar 2 as well, as only a phase shift between two successive lines can produce an (R-Y) output signal, in spite of the fact that the signal from the generator does not contain any (R-Y) information during that bar.

In this way it is possible to distinguish between phase and amplitude errors. The PAL-alternating burst is required to ensure the proper operation of the (R-Y) switch. Without alternating burst, no "Venetian blinds" would appear.

4. ● If the delay-line circuit is completely misaligned (e.g. after replacement of parts), it is advisable to follow the procedure described in section K "Adjusting with the oscilloscope" on page 58.

## H. Pattern 8.

"PHASE"




Fig. VII-18. "PHASE"-pattern

This pattern is designed especially for checking the chroma demodulators. The colour of the first bar is orange/yellowish, bar 2 is greenish, bar 3 is rose and bar 4 is grey.

This pattern consists of the same four vertical bars as the previous one. The upper part of the pattern is encoded according to the PAL alternating standard, while the lower part contains colour information only on every "positive"-PAL-line. The latter means that only those lines with a burst phase of  $135^\circ$  carry colour information. The burst is the normal PAL alternating burst for the entire pattern, see vectordiagram, Fig. VII-19.

To ensure the same colour impression of the upper and lower parts of the pattern, the upper part is generated with only half the chroma amplitude.



Fig. VII-19. Vectorscope display of the "PHASE"-pattern

1. ● Check and, if necessary, readjust the circuit of the subcarrier regenerator in the receiver according to the instructions in the Service Notes of the relevant set.
2. ● Check that the upper and lower parts of the pattern produce the same colours during the same vertical bars. If the colours differ, the chroma demodulators are not adjusted correctly.




Fig. VII-20. Incorrect subcarrier phase to the (R-Y) demodulator

3. ● A colour difference between the upper and lower parts of bar 2 ( $(R-Y) = 0$ ) indicates an incorrect subcarrier phase to the (R-Y) demodulator. See Fig. VII-20. Readjust until the colour difference has been eliminated.




Fig. VII-21. Incorrect subcarrier phase to the (B-Y) demodulator

4. ● A colour difference between the upper and lower parts of bar 3 ( $(B-Y) = 0$ ) indicates an incorrect subcarrier phase to the (B-Y) demodulator. See Fig. VII-21. Readjust until the colour difference has been eliminated.
5. ● If the chroma demodulators are completely misaligned (e.g. after replacement of parts), it is advisable to follow the procedure described in section K "Adjusting with the oscilloscope", page 58.




Fig. VII-22. Incorrect subcarrier phase to both demodulators (R-Y) and (B-Y)

6. ● In some receivers the subcarrier phase to both demodulators can be varied only simultaneously. In that case first adjust, for example, the (R-Y) demodulator to obtain a correct adjustment for bar 2 and then the (B-Y) demodulator for correct quadrature by observing bar 3, or vice versa. Since there may be considerable interaction between these adjustments, they often have to be repeated several times, see Fig. VII-22.

The receiver operates as a simple-PAL-receiver during the lower part of the pattern. Due to the type of signal applied the delay-line is inoperative and the effect of possible incorrectly adjusted chroma demodulators will not be neutralised. The upper part of the pattern is used as a reference, because owing to the PAL system, these colours will not change until very large phase errors occur in the demodulators (these colours will in fact only show a slight desaturation). The changing of the colour in the lower part of, for example, bar 2 (containing only (B-Y) information) is caused by the fact that, due to an incorrect phase setting of the (R-Y) demodulator, this modulator is 'opened' at the incorrect moments and therefore produces an undesired output signal during bar 2. This signal produces another colour in conjunction with the (B-Y) output signal.

I. **Pattern 9.**  
"MATRIX"




Fig. VII-23. "MATRIX"-pattern

This pattern produces the same colours on the screen as the previous pattern. However, these are more saturated. It is intended for checking, amongst others, the matrixing circuit.

This pattern consists of the same four vertical bars as the previous two patterns and is, the same as the burst, entirely encoded according to the PAL standard. It is identical to the upper part of the previous pattern, however with normal saturation, see vector diagram, Fig. VII-24.




Fig. VII-24. Vectorscope display of the "MATRIX"-pattern

1. ● Switch off the red and blue guns of the colour picture tube. The pattern on the screen now consists of four green bars. Bars 1 and 4 should have the same intensity, while bar 2 is more bright and bar 3 is less bright than bars 1 and 4.
2. ● Bars 1 and 4 should disappear (be cut off) at the same moment when the brightness control of the receiver is turned anti-clockwise. If not, the (G-Y)-output signal of the matrixing circuit is not correct. Readjust according to the instructions in the Service Notes of the relevant receiver.
3. ● If the circuitry is completely misaligned, (e.g. after replacement of parts), it is advisable to follow the procedure as described in section K "Adjusting with the oscilloscope", page 58.

**J. Pattern 10.**

"COLOUR BAR"




Fig. VII-25. "COLOUR BAR"-pattern

The upper part of this pattern is produced by the standard colour bar signal (75% contrast), see vector diagram, Fig. VII-26. The bars are arranged in the sequence of decreasing luminance. From left to right the bars are: white, yellow, cyan, green, magenta, red, blue and black. This pattern is used to set the "customer-controls" of the receiver to the correct positions (see section VI "OPERATION", pages 21 and 22).

The lower part of this pattern serves as a reference to enable adjusting the amplitude ratio of the colour-difference signals to the picture tube.




Fig. VII-26. Vectorscope display of the "COLOUR BAR"-pattern


In some types of colour television receivers (e.g. in the PHILIPS K7-type) normal cathode resistors have been used for the picture tube instead of VDR resistors (like in the PHILIPS K6-type)

As opposed to VDR resistors, normal resistors will cause negative feedback of the colour difference signals to the Wehnelt cylinders. On account of this the amplitude of these signals should be adapted to the degree of feedback. For servicing these types of receivers the "COLOUR-BAR" pattern consists of colour-bars with a white lower-section.


The white lower-section which has the same video amplitude as the white bar in the upper part, serves as a reference so that the amplitude ratio of the colour difference signals can be adjusted while using the picture screen as an indicator.



a. Saturation adjusted too low



b. Saturation adjusted correct




c. Saturation adjusted too high


Fig. VII-27. Blue-colourdifference-signal of "COLOUR BAR"-pattern

After the white adjustment(s) and grey scale have been checked, display the "COLOUR BAR" pattern.


1. ● With the aid of an oscilloscope check whether the amplitude of the (B-Y) signal corresponds to the value specified by the manufacturer of the set. If necessary, adjust the amplitude with control "AMPL (B-Y)".
2. ● Switch off the red and the green gun. Adjust the contrast and saturation controls so that there is no difference in brightness between the blue bars and the blue section at the bottom of picture (See Fig. VII-27).



a. Signal amplitude too low




b. Signal amplitude correct




c. Signal amplitude too high

Fig. VII-28. Red-colour-difference-signal of "COLOUR BAR"-pattern


3. ● Switch on the red gun and switch off the blue gun. If required, adjust "AMPL (R-Y)" so that there is no difference in brightness between the red bars and the red section at the bottom of the picture (See Fig. VII-28).



a. Signal amplitude too low



b. Signal amplitude correct




c. Signal amplitude too high

Fig. VII-29. Green-colourdifference signal of "COLOUR BAR"-pattern

4. ● Switch on the green gun and switch off the red gun. If required, adjust controls "PHASE (G-Y)" \* and "AMPL (G-Y)" so that there is no difference in brightness between the green bar and the green section at the bottom of the picture (See Fig. VII-29).
5. ● Switch on the red and the blue gun again.

\* Control "PHASE (G-Y)" will have to be used mainly to eliminate differences in brightness in the upper green bar (See Fig. VII-29d).



d. Signal phase incorrect

Fig. VII-29. Green-colourdifference-signal of "COLOUR BAR"-pattern

The "COLOUR BAR"-pattern can also be used for a number of checks and adjustments described in the Service Notes of the receiver, e.g.:

- checking the burst keying
- checking the colour AGC and the colour killer circuit (by operating control "BURST AMPL.").
- checking the reactance circuit of the subcarrier regenerator.
- checking the synchronisation of the subcarrier regenerator.
- checking the PAL identification circuit.

**Note:**

In case of fault-finding in a receiver by means of following the signal through the various circuits, it is recommended, to employ a simpler pattern like e.g. "MATRIX" instead of the "COLOUR BAR" pattern.

### K. Adjusting with the oscilloscope




Fig. VII-30. Correctly adjusted delay-line

For carrying out the adjustments described below, we recommend the use of the dual-beam oscilloscope PHILIPS PM 3230.

#### 1. Connections and oscilloscope-settings for adjusting the delay-line circuit and the chroma demodulators.

- connect the  $Y_A$ -input of the oscilloscope to the "red" grid of the picture tube via an attenuator probe.
- connect the  $Y_B$ -input of the oscilloscope to the "red" grid of the picture tube via an attenuator probe.
- Trigger the oscilloscope externally with the line sync. pulses from sockets "SYNC." (switch "SYNC." in position "LINE").
- Adjust the time-base settings of the oscilloscope to obtain  $2\frac{1}{4}$  TV-line periods on its screen, so that two successive TV-lines coincide. **Only** then you will be able to notice any misalignments.




Fig. VII-31. Amplitude error in delay-line




Fig. VII-32. Phase error in delay-line (notice the deviation of the (B-Y) signal in respect with Fig. VII-31)

## 2. Adjusting the delay-line circuit

- Depress push-button "DELAY".
- Adjust the phase and amplitude controls of the delay-line so that the signal to the red grid is zero, see Fig. VII-30 (upper trace (R-Y), lower trace (B-Y)). It may seem that two successive lines on the scope screen show a different signal level, so that the result (two TV-lines onto each other) cannot be made zero. This is an indication of cross-talk between the (B-Y) and (R-Y) channel of the receiver. In case of incorrect adjustments, oscillograms as shown in Fig. VII-31 and Fig. VII-32 will be measured (upper trace: (R-Y), lower trace: (B-Y)).

**Note:** The time base speed of the oscillograms is approx.  $6.5 \mu\text{s}/\text{division}$ .




Fig. VII-33. Both demodulators adjusted correctly

### 3. Adjusting the chroma-demodulators

— Depress push-button "PHASE".

- Adjust both demodulator phases to obtain an oscillogram as shown in Fig. VII-33.

Figs. VII-34, VII-35 and VII-36 show oscillograms that will be obtained in case of incorrectly adjusted demodulators. If the (R-Y) signal cannot be made correct for both successive TV lines, the (R-Y) switch of the receiver does not switch exactly  $180^\circ$ .

**Note:** The time base speed of the oscillograms is approx.  $6.5 \mu\text{s}/\text{division}$ .




Fig. VII-34. Only (R-Y) demodulator adjusted incorrectly




Fig. VII-35. Only (B-Y) demodulator adjusted incorrectly




Fig. VII-36. Both demodulators adjusted incorrectly




Fig. VII-37. Correct (G-Y) signal

**4. Checking the (G-Y) output signal of the matrixing circuit**

- Connect the Y-input of the oscilloscope to the "green" grid of the picture tube via an attenuator probe.
- Trigger the oscilloscope externally with the line sync. pulses from sockets "SYNC." (switch "SYNC." in position "LINE").
- Adjust the time base settings of the oscilloscop so that one TV-line appears on its screen.
- Depress push-button "MATRIX".






Fig. VII-38. Incorrect (G-Y) signal


- The level of bar 1 ((G-Y) = 0) and bar 4 (grey) should both be zero on the oscilloscope, see Fig. VII-37. If not, the signal from the matrixing circuit is not correct. Because the (G-Y) signal is actually matrixed from the (R-Y) and (B-Y) signals, the fault will not necessarily be due to an incorrect matrix, but could also be caused by, for example, an incorrect ratio of the output signals of the delay line and/or the demodulator circuits. Fig. VII-38 shows an incorrect (G-Y) output signal of the matrix.
- If the "zero"-level of green does not remain the same as for grey when the contrast and saturation controls of the receiver are operated, the chroma gain is too high (incorrect chroma AGC) so that the (R-Y) and/or (B-Y) signal is clipped, as a result of which their ratio changes and the (G-Y) signal also changes.

**Note:** The time base speed of the oscillograms is approx.  $6.5 \mu\text{s}/\text{division}$ .







UNIT 1 - POWER SUPPLY





UNIT 2a - LINE INFORMATION


COLOUR BAR GENERATOR













UNIT 4b - COLOUR ENCODER



BSY 38 = BSX20



## Sales and service all over the world



- Argentina:** Philips Argentina S.A., Casilla Correo 3479, Buenos Aires; tel. T.E. 70, 7741 al 7749
- Australia:** Philips Electrical (Pty) Ltd., P.O.B. 2703 G.P.O., 69-79 Clarence Street, Sydney; tel. 20-223
- België/Belgique:** M.B.L.E., 80 Rue des Deux Gares, Bruxelles; tel. 230000
- Bolivia:** Philips Sudamericana, Casilla 1609, La Paz; tel. 5270-5664
- Brasil:** Messrs. Inbelsa, Rua Amador Bueno 474, Caixa Postal 3159, Sao Paulo; tel. 93-9191
- Burma:** U. Thoung Tin, 36, Barr Street, Rangoon
- Burundi:** Philips S.A.R.L., Avenue de Grèce, B.P. 900, Bujumbura.
- Canada:** Philips Electronic Industries, Electronic Equipment Division, 116 Vanderhoof Avenue, Toronto 17, Ontario; tel. 425-5161
- Chile:** Philips Chiléna S.A., Casilla 2687, Santiago de Chile; tel. 35081
- Colombia:** Philips Colombiana S.A., Communications Department, Apartado Nacional 1505, Bogotá; tel. 473-640
- Congo:** Philips S.A.R.L., 620, Avenue Industrielle, B.P. 2546, Lubumbashi; Philips Congo S.C.R.L., 137, Boulevard du 30 Juin, B.P. 1798, Kinshasa; 52, Avenue des Eucalyptus, B.P. 2020, Kisangani
- Costa Rica:** Philips de Costa Rica Ltd., Apartado Postal 4325, San José; tel. 5670
- Curaçao:** Philips Antillana N.V., Postbus 523, Willemstad; tel. Curaçao 36222-35464
- Danmark:** Philips A.S., Prags Boulevard 80, København; tel. Asta 2222
- Deutschland (Bundesrepublik):** Philips Industrie Elektronik GmbH, Röntgenstrasse 22, Postfach 630111, 2 Hamburg 63; tel. 501031
- Ecuador:** Philips Ecuador S.A., Casilla 343, Quito; tel. 30064
- El Salvador:** Philips de El Salvador, Apartado Postal 865, San Salvador; tel. 7441
- Espana:** Philips Ibérica S.A.E., Avenida de America, Apartado 2065, Madrid; tel. 246 22 00
- Ethiopia:** Philips Ethiopia (Priv. Ltd., Co.), P.O.B. 659, Cunningham Street, Addis Abeba; tel. 13440
- France:** Philips Industrie S.A., 105 Rue de Paris, 93 Bobigny (Seine); tel. 845 28-55, 845 27-09
- Ghana:** Philips (Ghana) Ltd., P.O.B. M 14, Accra
- Great Britain:** Pye Unicam Ltd., Manor Royal, Crawley (Sussex); tel. 28787
- Guatamala:** Philips de Guatamala S.A., Apartado Postal 238, Guatamala City; tel. 20607-08-09
- Hellas:** Philips S.A. Hellénique, B.P. 153, Athènes; tel. 230476
- Hong Kong:** Philips Hong Kong Ltd., P.O.B. 2108, Rooms 1006/1008 Prince's Building, Hong Kong; tel. 33728, 28548
- India:** Philips India Ltd., Shivsagar Estate, Block "A", Dr. Annie Besant Road, P.O.B. 6598, Worli, Bombay 18, tel. 246-231; 245-144
- Indonesia:** Philips Delegate Office, Djalan Pegangsaan Timur 33, P.O.B. 2287, Djakarta.
- Iran:** Philips Iran Ltd., P.O.B. 1297, Teheran; tel. 48344-68344
- Ireland:** Philips Electrical (Ireland) Ltd., Newstead, Clonskeagh, Dublin 14; tel. 976611
- Island:** Mr. Snorri P.B. Arnar, P.O.B. 354, Reykjavik; tel. 13869
- Islands Canarias:** Philips Ibérica S.A.E., Triane 132, Las Palmas; Castilla 39-41 Santa Cruz de Tenerife

- Italia:** Philips S.p.A., Casella Postale 3992, Milano; tel. 69.94
- Kenya:** Philips (Kenya) Ltd., P.O.B. 9970, Nairobi
- Malaya:** William Jacks & Co. Ltd., 8, Jalon Mountbatten, P.O.B. 286, Kuala Lumpur
- Malaysia:** Philips Singapore Ltd., 8th Floor, International Bld, 360 Orchard Road, P.O.B. 1358, Singapore; tel. 9914 Messrs. William Jacks and Co. 63/4 m.s. Bukit Timah Road, P.O.B. 4049, Singapore
- Mexico:** Philips Comercial S.A. de C.V. Uruapan 7, Apdo 24-328, Mexico 7 D.F.
- Nederland:** Philips Bedrijfsapparatuur Nederland N.V., Boschdijk VB, Eindhoven; tel. 3-33-33
- Ned. Antillen:** Philips Antillana N.V., Postbus 523, Willemstad; tel. Curaçao 36222-35464
- New Zealand:** Electronic Development and Applications Co. Ltd., 18-20 Lorne Street, P.O.B. 6415, Wellington; tel. 54-039
- Nigeria:** Philips (Nigeria) Ltd., Philips House, 6, Ijora Causeway, P.O.B. 1921; Lagos; tel. 56051/2
- Nippon:** Philips Products Sales Corporation of Japan, Kokusai Building, 7th Floor, Marunouchi, Chiyoda-Ku, Tokyo; tel. (216) 2441
- Norge:** Norsk A.S. Philips, Postboks 5040, Oslo; tel. 463890
- Osterreich:** Philips GmbH, Abt. Industrie, Triesterstrasse 64, 1101 Wien X; tel. 64 55 11
- Pakistan:** Philips Electrical Co. of Pakistan Ltd., Bunder Road, P.O.B. 7101, Karachi; tel. 70071
- Paraguay:** Philips del Paraguay S.A., Casilla de Correo 605, Asunción; tel. 8045-5536-6666
- Perú:** Philips Peruana S.A., Apartado Postal 1841, Lima; tel. 34620-40265
- Philippines:** Electronic Development & Application Center, Room 715, Don Santiago Bld., 1344 Taft Avenue, Manila
- Portugal:** Philips Portuguesa S.A.R.L., Rua Joaquim Antonio d'Aquiar 66, Lisboa; tel. 683121/9
- Rhodesia:** Philips Rhodesian (Private) Ltd., P.O.B. 994, Gordon Avenue, Salisbury; tel. 29081
- Rwanda:** Philips Rwanda S.A.R.L., B.P. 448, Kigali
- Schweiz-Suisse-Svizzera:** Philips A.G., Binzstrasse 38, 8027 Zürich; tel. 051 44 22 11
- South Africa:** South African Philips (Pty) Ltd., P.O.B. 7703, 2, Herb Street, New Doornfontein, Johannesburg; tel. 24-0531
- Suomi:** Oy Philips Ab, P.O.B. 10255, Helsinki 10; tel. 10915
- Sverige:** Svenska A.B. Philips, Fack, Lidingövägen 50, Stockholm 27; tel. 08/635000
- Taiwan:** Yung Kang Trading Co. Ltd., 6 Nan King East Road, 1 Section, P.O.B. 1467, Taipei; tel. 43540
- Tanzania:** Philips (Tanzania) Ltd., P.O.B. 20104, Dar Es Salaam
- Thailand:** Philips Thailand Ltd., 283 Silom Road, Bangkok; tel. 36985-8
- Türkiye:** Türk Philips Ticaret A.S., Posta Kutusu 504, Istanbul; tel. 447486
- Uruguay:** Philips de Uruguay, Avda Uruguay 1287, Montevideo; tel. 956 41-2-3-4
- U.S.A.:** Philips Electronic Instruments, 750 South Fulton Ave., Mount Vernon, N.Y. 10550; tel. (914) 664-4500
- Venezuela:** C.A. Philips Venezolana, Apartado Postal 1167, Caracas; tel. 72 01 51
- Zambia:** Philips Electrical Ltd., P.O.B. 1878, Lusaka

